




Sauna Icon 125, Ø200

(Front: glass wall)



Sauna "Icon" 125,Ø200




















Note: Please read manual before construction.

(TIC20/125KE-PT01)















Sauna "Icon" 125,Ø200

Details list 1/4

DET 1 Article. K-SM100/1050	x2		
DET 2 Article. K-SM100/1300	x3		
DET 3 Article. T-STL117/1250XLM02	x1		
DET 3a Article. T-STL117/1250-01	x65		
DET 3a/H Article. T-STL117/1250-01X	x2		
DET 6 DET 3 vastaspool Article. T-STL117/1250XL-01	x2		
DET Frame (Front glass-wall) Article. IC-20-TKE12/15-USA	x1		
DET Glass (Front glass-wall) Article. IC-20-ES	x2		
DET Ta Article. T-SL117/610UK1	x1		
DET Tb Article. T-TL94/610J	x1		












Sauna "Icon" 125,Ø200

Details list 2/4

DET Y1 Article. T-IC20-PTS/28-V	x1 		
DET Y2 Article. T-IC20-PTS/28-P	x1 		
DET 10a Article. K-HP44/490XP	x2 		
DET 10c Article. K-HP44/170	x1 		
DET 10 Article. TL-LAMOD-1930-01	x1 		
DET 11a Article. K-HP44/652	x1 		
DET 11 Article. TL-LAMOD-1250-01	x1 		
DET 11b Article. K-HP44/250XP-XP	x1 		
DET 14 Article. TL-STMOD-1930-01	x1 		












Sauna "Icon" 125,Ø200

Details list 3/4


DET 21	x1		
Article. U-6/17			
DET 21c	x2		
Article. K-HP44/1690			
DET 21d	x2		
Article. K-HP44/680			
DET 21a	x2		
Article. K-HL44/1660			
DET 21b	x2		
Article. K-HL44/650			
DET 16	x1		
Article. TL-PIMOD-634-01			
DET 15	x1		
Article. TL-LAV90/498			
DET 22	x2		
Article. T-STL-1250-XX			
DET 25a	x8		
Article. MU-OL-IC-20-1			
DET 25b	x8		
Article. MU-OL-IC-20-2			

Sauna "Icon" 125,Ø200


Details list 4/4

Underlay felt Article. KAT-AL	8 m. 		
DET N Article. KAT-HAR	x5 		
DET O Article. KAT-SIN	x42 		
DET W Article. MU-TRAPP	x1 kmpl 		
DET V Article. KI-VIN-25/40/40-ZN	x4 		
DET A1 Article. MU-VIT10/2200	x2 		
DET A2 Article. MU-VIT10/5200	x2 		
DET B Article. MU-VITKL-RV	x8 		
DET G Article. MU-VENT-100-PU	x1 		
DET F Article. MU-VENT-100-ZN	x3 		
Article. KI-KERL-12-RV4 	Article. KI-ICO-160-220 		


Sauna "Icon" 125,Ø200



Sauna "Icon" 125,Ø200




Fix screws over the one board, diagonally in every board.




Sauna "Icon" 125, Ø200

Front glass wall assembly



Front glass wall assembly


Apply waterproof
● silicone ●



(TIC20/125KE-PT01)


Sauna "Icon" 125,Ø200

Wooden back wall assembly





Sauna "Icon" 125,Ø200

Use waterlevel




Make sure the marking on the wall is centered in the notch.





Sauna "Icon" 125,Ø200

Use waterlevel








Make sure the marking on the wall is centered in the notch.




II

• 2x H •


Sauna "Icon" 125,Ø200





Sauna "Icon" 125,Ø200





I



II







III








IV

Sauna "Icon" 125,Ø200




Sauna "Icon" 125,Ø200




Sauna "Icon" 125,Ø200


Use waterlevel for installation!




Sauna "Icon" 125,Ø200



I



II





III

Sauna "Icon" 125,Ø200

1x DET 21




Attention!
The door must open outwards. If you need the door handle to be on the opposite side, rotate door 180 degrees.




Ensure door frame is pressed tightly against the wall and fasten from inside.




Use waterlevel.





Sauna "Icon" 125,Ø200





Please be careful!!! Do not hit the glass with the screw.




I



II





Sauna "Icon" 125,Ø200



Sauna "Icon" 125,Ø200

Underlay felt installation manual.



Attention! Refer to underlay installation manual provided in package.




III

Sauna "Icon" 125,Ø200



Attention! Refer to shingle installation manual provided in package.





Attention! Refer to shingle installation manual provided in package.



Sauna "Icon" 125,Ø200



Leave small gap between boards.



Leave small gap between boards.